# Wireless Client Configuration Guide

for 3rd-party wireless Ethernet cards

#### Notice to Users

©2002 2Wire, Inc. All rights reserved. This manual in whole or in part, may not be reproduced, translated, or reduced to any machine-readable form without prior written approval.

2WIRE PROVIDES NO WARRANTY WITH REGARD TO THIS MANUAL, THE SOFTWARE, OR OTHER INFORMATION CONTAINED HEREIN AND HEREBY EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE WITH REGARD TO THIS MANUAL, THE SOFTWARE, OR SUCH OTHER INFORMATION, IN NO EVENT SHALL 2WIRE, INC. BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, WHETHER BASED ON TORT, CONTRACT, OR OTHERWISE, ARISING OUT OF OR IN CONNECTION WITH THIS MANUAL, THE SOFTWARE, OR OTHER INFORMATION CONTAINED HEREIN OR THE USE THEREOF.

2Wire, Inc. reserves the right to make any modification to this manual or the information contained herein at any time without notice. The software described herein is governed by the terms of a separate user license agreement.

Updates and additions to software may require an additional charge. Subscriptions to online service providers may require a fee and credit card information. Financial services may require prior arrangements with participating financial institutions.

2Wire, the 2Wire logo, and HomePortal are trademarks of 2Wire, Inc. All other trademarks are trademarks of their respective owners.

#### **Owner's Record**

The serial number is located on the bottom of your 2Wire HomePortal. Record the serial number in the space provided here and refer to it when you call Customer Care.

Serial Number:

#### **Safety Information**

- To prevent fire or shock hazard, do not expose your HomePortal to rain or moisture.
- To avoid electrical shock, do not open the HomePortal. Refer servicing to qualified personnel only.
- Never install modem or telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wire or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- Avoid using your modem during an electrical storm.
- Do not use your modem or a telephone to report a gas leak in the vicinity of the leak.
- A socket outlet should be as close as possible to the unit and easily accessible.

# Contents

#### Wireless adapter configuration

Introduction	1
Locate the serial number and wireless encryption key	1
Agere ORiNOCO PC Card - Silver or Gold	3
Cisco Aironet	8
D-Link Air DWL-650	. 13
Apple AirPort card	. 16
Other wireless Ethernet adapters	. 18
Wireless configuration with Windows XP	. 19

#### Contents

# **Wireless adapter configuration**

#### Introduction

After your 802.11b wireless adapter is installed in your computer, you must configure it to communicate with the HomePortal. This guide describes how to configure the following wireless Ethernet (IEEE 802.11b) adapters for performance with the HomePortal:

- Agere (ORiNOCO PC Card Silver or Gold)
- Cisco (Aironet 340 Series 11Mbps Wireless LAN Adapter)
- D-Link Air DWL-650
- Apple AirPort card
- Other third-party wireless Ethernet cards

**Note:** The instructions for Agere, Cisco, and D-Link cards are for computers running Windows 98. The instructions for the Apple card are for computers running MacOS 9.0[??]. Because not all Windows and Macintosh versions respond to new hardware in the same way, screens may appear in a different order and may have a slightly different appearance than the screens shown in these instructions.

#### Locate the serial number and wireless encryption key

Your HomePortal is configured with unique security paramters that must be configured into your wireless adapter.

#### **Wireless Card Configuration**

On the bottom of your HomePortal you will find two important pieces of information required for configuring your adapter: the serial number and the wireless encryption key.




After you have located the serial number and wireless encryption key, perform the following steps to configure your wireless adapter.


## **Agere ORiNOCO PC Card - Silver or Gold**

Consult the documentation provided with your wireless adapter to install the Agere ORiNOCO PC Card - Silver or Gold, then follow these steps:

1. From the Start menu, select **Programs > ORiNOCO > Client Manager**. The ORiNOCO Client Manager screen appears.



2. From the Actions menu, select Add/Edit Configuration Profile.



**3.** The Add/Edit Configuration Profile screen appears.

Add/Edit Conl	figuration Prof	ile	?	×
Default		•	Add	
			Edit	
			<u>D</u> elete	
	n to: wireless profile fi r Delete a user-d			
	<u>0</u> K	<u>C</u> ancel	<u>H</u> elp	

4. Click Add. The Edit Configuration screen appears. Enter a profile name in the Profile Name field. The profile name identifies your wireless profile, and should be no more than 29 characters in length.

Sedit Configuration	? ×
Select Profile	
Profile Name:	Network <u>T</u> ype:
2Wire	Access Point
<ul> <li>Use this screen to assign a n</li> <li>Select the Network Type to it wireless connection for this pr</li> </ul>	dentify the type of
< <u>B</u> ack.	Next > Help

5. From the Network Type pulldown menu, select Access Point.

6. Click Next. The Edit Configuration screen appears.


SEdit Configuration
Identify Your Network
Network N <u>a</u> me:
2WIRE806 Scan
<ul> <li>Use this screen to identify the Network Name of the wireless network to which you wish to connect your computer.</li> </ul>
< Back Next > Help

- 7. In the Network Name field, enter the word "2WIRE" followed by the last three digits of your HomePortal serial number, located on the bottom of your HomePortal. This is the Wireless Network Name. The Wireless Network Name is case-sensitive, so it is important that you enter the word "2WIRE" in capital letters.
- 8. Click Next. In the Set Security field, check the Enable Data Security checkbox. Verify that the Use Hexadecimal (0-9, a-f, A-F) radio button is selected.

Sedit Configuration	? ×
Set Security	
<ul> <li>Enable Data Security</li> <li>Use Alphanumeric Characters (0-9, a-z, A-Z)</li> <li>Use Hexadecimal (0-9, a-t, A-F)</li> </ul>	
Key 6686867787 Key 2 Key 3 Key 4	
Engrypt data with: Key 1	
< <u>B</u> ack <u>N</u> ext > Help	

**9.** In the Key field, enter your ten-digit Wireless Encryption Key, located on the bottom of your HomePortal.

- **10.** Verify that **Key 1** is selected in the **Encrypt data with** pulldown menu (this is the default).
- 11. Click Next. The following screen appears.



- **12.** Select the power management option that you wish to use (the default is **Off**), and click **Next**.
- **13.** In the TCP/IP Behavior field, check the **Renew IP Address when selecting this profile** checkbox.



2Wire		•	<u>A</u> dd
			<u>E</u> dit
			<u>D</u> elete
	a wireless profi	le from the pull-d er-defined wirele:	


**14.** Click **Finish**. The following screen appears.

**15.** Click **OK**.

## **Cisco Aironet**

Consult the documentation provided with your wireless card to install the Cisco Aironet adapter, then follow these steps:

1. Double-click the Aironet Client Utility icon on your desktop. The Aironet Client Utility screen appears.



- 2. Click the **Profile Manager** button. The Profile Manager screen appears.
- 3. Click Add.

**4.** In the Profile Management field, enter your profile name. The profile name identifies your wireless profile, and should be no more than 29 characters in length.

	Use Selected Profi Use Auto Profile Selectic		nced I ab Settings
Allow Windows To Conf	igure My Wireless Network Setting	· · · · · · · · · · · · · · · · · · ·	° Only)
Profile Management			
2wire			Add
	Ŧ		<u>E</u> dit
_			<u>R</u> ename
🗖 Ind	ude Profile In Auto Profile Selectio	n	<u>D</u> elete
Įm;	port E <u>x</u> port		Ise Defaults

5. Click Apply. The 340 Series Properties screen appears.

**6.** Select the **System Parameters** tab. In the Client Name field, enter a client name. The client name identifies your PC.

340 Series Properties - [2₩ire]	×
System Parameters   RF Network   Advanced (Infrastruc	ture) Network Security
Client Name: Wireless Lapton SSID1: ZWIRE806 SSID2: SSID3: Power Save Mode: © <u>C</u> AM (Constantly Awake Mode) © <u>Max PSP (Max Power Savings)</u> © <u>Fast PSP (Power Save Mode)</u>	Network Type: C ≜d Hoc C Infrastructure Defaults
	OK Cancel Help

- 7. In the SSID1 field, enter the word "2WIRE" followed by the last three digits of your HomePortal serial number. This is the Wireless Network Name. The Wireless Network Name is case-sensitive, so it is important that you enter the word "2WIRE" in capital letters.
- **8.** In the Power Save Mode field, verify that the **CAM (Constantly Awake Mode)** radio button is selected (this is the default).
- **9.** In the Network Type field, verify that the **Infrastructure** radio button is selected (this is the default).

**10.** Select the Network Security tab. In the WEP field, select the **Use Static WEP Keys** radio button.

340 Series Properties - [2'Wire] System Parameters   RF Network   Advanced (Infrastructure	Network Security
Network Security Type: None Configure	WEP © No WEP © Use Static WEP Keys © Use Dynamic WEP Keys
WEP Key Entry Method:	Access Point Authentication: © Open Authentication © Shared Key Authentication WEP Key Size 40 128 © C © C © C © C
Allow Association To Mixed Cells	<u>D</u> efaults
	OK Cancel Help

- **11.** In the WEP Key Entry Method field, verify that the **Hexadecimal (0-9, A-F)** radio button is selected.
- **12.** In the WEP Key 1 field, click the **Transmit Key** radio button and enter your ten-digit Wireless Encryption Key, located on the bottom of your HomePortal.

**13.** Click **OK**. The Profile Manager screen appears. Your profile name should now appear in the second line of the Profile Management field, indicating that your Cisco adapter is properly configured.


	Use Selected Profile C 2Wir Use Auto Profile Selection C	e
	is To Configure My Wireless Network Settings O (Win	dows XP Onlu)
Profile Manage	ment	
	2Wire	<u>A</u> dd
	2Wire	<u>E</u> dit
		 <u>R</u> ename
	Include Profile In Auto Profile Selection	
		<u>D</u> elete
	Import Export	Use Defaults

14. Click OK.

# **D-Link Air DWL-650**

Consult the documentation provided with your wireless adapter to install the D-Link Air DWL-650, then follow these steps:

1. From the Start menu, select **Programs > D-Link DWL-650 Control Utility > Configuration Utility**.



D-Link Air DWL-650 Configuration
Link Info Configuration Encryption About
State Scanning Current Channel 6 Current Tx Rate 2 Mbits/s
Throughput (Bytes/sec) Tx 0 Rx 0
Link Quality: Not Applicable
Signal Strength: Not Applicable
OK Cancel Help

2. The D-Link Air DWL-650 Configuration screen appears.

**3.** Click the Configuration tab.

L D-Link Air DWL-650 Configuration
Link Info Configuration Encryption About
Mode Infrastructure
SSID 2WIRE806
Tx Rate Fully Automatic
PS Mode Disabled
Channel
Restore Defaults Undo Changes Apply Changes
OK Cancel Help

- 4. In the Mode field, enter Infrastructure.
- 5. In the SSID field, enter the word "**2WIRE**" followed by the last three digits of your HomePortal serial number. This is the Wireless Network Name. The

Wireless Network Name is case-sensitive, so it is important that you enter the word "**2WIRE**" in capital letters.

- 6. In the Tx Rate pulldown menu, verify that Fully Automatic is selected (this is the default).
- **7.** In the PS Mode pulldown menu, verify that **Disabled** is selected (this is the default).
- 8. Click Apply Changes.
- 9. Click the Encryption tab.

Link Air DWL-650 Configuration			
Link Info Configuration Encryption About			
Your encryption settings must match those of your network, or your computer will be unable to communicate.			
Encryption (WEP) 64 Bit			
WEP Key Entry C Create with Passphrase			
Passphrase			
Manual Entry			
Key 1 66 86 86 77 87			
Key 2 xx xx xx xx			
Key 3 XX XX XX XX			
Key 4 xx xx xx xx			
Default Tx Key 🛛 💌			
OK Cancel Help			

- **10.** From the Encryption (WEP) pulldown menu, select **64-bit**.
- **11.** In the WEP Key Entry field, click the **Manual Entry** radio button.
- **12.** In the Key 1 field, enter your ten-digit Wireless Encryption Key, located on the bottom of your HomePortal.
- **13.** From the Default Tx Key pulldown, select **1**.
- 14. Click Apply.
- **15.** Click **OK**.

# **Apple AirPort card**

Note: Requires AirPort client software revision 2.0 or greater.

Consult the documentation provided with your wireless adapter to install the Apple AirPort wireless adapter, then follow these steps:

1. From the Apple pull-down menu, select **AirPort** to open the AirPort dialog box.



2. From the AirPort dialog box, click the **Choose Network: AirPort Network** pull-down menu.

	AirPort
Status	
AirPort Network 232936 Status not available	
⇒ Hide Settings	
AirPort	
AirPort: On	Turn AirPort Off
AirPort ID:	00 30 65 10 0D 20
	Allow selection of closed networks
AirPort Network	
Choose network:	AirPort Network 232936 🔹
Signal level:	
Base Station ID:	00 60 1D 23 29 36
② Software Base Sta	ation

**3.** From the AirPort Network pull-down menu, choose your wireless network name. Your wireless network name is "**2WIRE**" followed by the last three digits of your HomePortal serial number, located on the bottom of your HomePortal.

	AirPort
Status AirPort Network 232936 Status not available	
➡ Hide Settings AirPort	
AirPort: On	Turn AirPort Off
AirPort ID:	00 30 65 10 0D 20
_AirPort Network	Computer to Computer
Choose network:	AirPort Network 232936     Support Network 232936
Signal level:	2WIRE304
Base Station ID:	0197a6 AirPort Network 1eed85
	1d3eb4Apple AirPort
Software Base Sta	cion

**4.** In the Password field, enter "**\$**" followed by your ten-digit Wireless Encryption Key, located on the bottom of your HomePortal.

The selected AirPort network requires a password to join.	
Password:	•••
🗌 Add to Keychain	Cancel OK

5. Click OK.

#### **Other wireless Ethernet adapters**

**Note:** The following steps are completed using the configuration program provided with your wireless adapter. If you have not already done so, install the wireless adapter configuration software before continuing.

1. Set the network type to **Infrastructure**.

Refer to your wireless card documentation for instructions on editing the card's network profile. Your wireless card should be configured to operate with an access point or residential gateway. This mode of operation is typically enabled by setting network type to Infrastructure.

2. Set the wireless network name.

The wireless network name of your HomePortal is **2WIRE** in all capital letters, followed by the last three digit of the HomePortal serial number located on the bottom your HomePortal. For example, if the last three digits of your HomePortal serial number are 102, your HomePortal network name would be 2WIRE102.

The wireless network name is sometimes referred to as the **Network Name**, **SSID**, **ESS ID**, or **Wireless LAN ID**.

**3.** Enable wireless security.

Your HomePortal is pre-configured to take advantage of wireless security. Referring to the instructions provided with your wireless card, enable wireless security.

Wireless security is sometimes referred to as **WEP** (wired equivalent privacy), **64-bit encryption**, or **40-bit encryption**.

4. Enter the encryption key.

Once you have enabled security on your wireless card, you need to enter the unique security key for your HomePortal. To do this, set the network encryption type to **hexadecimal**, and enter your 10-digit wireless encryption key found on the bottom of your HomePortal.

5. In general, accept your card's defaults.

The default value for the remainder of configurable settings for your network card should allow your wireless card to communicate with the HomePortal.

Although the HomePortal is set by default to communicate using channel 6, it is not required to change your card to this setting as most cards will automatically detect the appropriate channel.

# Wireless configuration with Windows XP

**Note:** The following steps are completed using the configuration program provided with Windows XP. Make sure that the drivers for your adapter support Windows XP.

Windows XP is designed to handle wireless configuration in a generic fashion, provided that the manufacturer's drivers support Windows XP.

1. Right-click the Wireless Network Connection icon, located in the systray.



2. Select View Available Wireless Networks.



**3.** The Connect to Wireless Network screen appears. From the **Available networks** pane, select your wireless access point. The wireless access point

displays as "**2WIRE**" in all capital letters, followed by the last three digit of the HomePortal serial number (located on the bottom of your HomePortal).

Connect to Wireless Network
The following network(s) are available. To access a network, select it from the list, and then click Connect.
Available networks:
1 2w/IRE806
1 2WIRE002
1 2WIRE915
1 2WIRE340
This network requires the use of a network key (WEP). To access this network, type the key, and then click Connect.
Network key:
If you are having difficulty connecting to a network, click Advanced.
Advanced Cancel

**4.** In the **Network key** pane, enter your ten-digit Wireless Encryption Key, located on the bottom of your HomePortal.

Connect to Wireless Network				
The following network(s) are available. To access a network, select it from the list, and then click Connect.				
Available networks:				
1 2WIRE806				
🗼 2WIRE002				
1 2WIRE915				
1 2WIBE340				
This network requires the use of a network key (WEP). To access this network, type the key, and then click Connect.				
Network key: 6686867787				
If you are having difficulty connecting to a network, click Advanced.				
Advanced Connect Cancel				

5. Click Connect.